



Wildog Accessories

Installation instruction

PRODUCT DESCRIPTION:

- Ford ranger next generation rear



PRODUCT SAFETY & LEGAL DISCLAIMER

• IMPORTANT READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING. FAILURE TO DO SO MAY CAUSE PERSONAL INJURY OR DAMAGE TO PRODUCT AND/OR PROPERTY.

- Review the product package and contents prior to beginning the installation.

Take care when opening the packaging and removing items. If a return is needed you will want to return the product in its original packaging if possible.

- This instruction guide is provided as a GENERAL installation guide, some vehicles vary dimensionally and may require additional steps.
- Test fit the product on the vehicle prior to any third party modifications and or finishing. The manufacturer and/or distributors do not accept responsibility for third party charges, labor and or third part replacement modifications. Some modifications may void the factory warranty.
- Exercise due-diligence when installing this product. The manufacturer and distributors of this product do not accept any responsibility for vehicle damage or personal injury resulting from the installation of this product. Careless installation and operation can result in serious injury or equipment damage.
- This product is for general off-road use. All liability for installation and use rests with the owner/operator.



Wildog Accessories

Installation instruction

PARTS INCLUDED IN THE LIST:

A	Complete & assembled rear bumper Spine	1
B	Complete & assembled Rear bumper Shell	1
C	Recovery Points	2
D	M12 x 50 Hex Bolts	8
E	M12 x 25 Flat washers	8
F	M12x30x3 Washers	8
G	M12 Nyloc Nuts	8

A



B



C



D



E



F



G





Wildog Accessories

Installation instruction

Please insure that all parts and fasteners are accounted for before starting the fitment, if any parts are not included please give us a call on [065 100 62525](tel:06510062525) or [074 227 1524](tel:0742271524) and we will gladly assist you.

ESTIMATED TIME FOR INSTALLATION:

2-3 hours

Please follow the necessary steps to complete your fitment.

BEFORE

AFTER



STEP 1

Remove the following from the vehicle:

- Plastic bumper
- All Wiring and harnesses for the standard bumper.
- Remove the standard rear tow bar from the vehicle's standard chassis mounts. If there is an existing towbar.





Wildog Accessories

Installation instruction

Step 2

- Fit the Supplied spine to the chassis legs.
- Tighten the bolts on the Spine/Chassis and torque to 95NM.
- Spray the bolts and mark with paint marker after tightened.





Wildog Accessories

Installation instruction

Step 5

- Fit the Supplied Shell to the spine and fasten the recovery point on the shell. The recovery point mounts through the spine and shell to secure the shell to the spine.





Wildog Accessories

Installation instruction

STEP 6

- Insert the PDC Holders into the existing holes on the bumper from the front side and then insert the sensor from the rear into the original holder



PDC Sensor and holder



PDC Harness



- Reconnect the PDC sensors to the existing harness.
- Connect the numberplate light on the bumper to the existing harness of the vehicle.

- Please ensure that all parts and fasteners are fitted and tightened before letting the vehicle leave your premises.
- Retention all fasteners after 3 months or 500KM of installation to ensure all parts are still fastened and safe for the client.

Here is too many safe adventures.



Wildog Accessories

Installation instruction

A Warranty form is included with all Wildog Accessories orders placed, please ensure that it is completed with every fitment and retention of the bumper if there is no Warranty form completed your 1-year Warranty on the bumper will be voided



Wildog Accessories (Pty) Ltd

www.wildog.co.za
 sales@wildog.co.za
 17 Akwamaryn Street
 Klerksoord Pretoria

Contact numbers:
 0651006252
 0742271524

Jobcard

Fitment Centre Reference:

Date:

INSTALLATION AND WARRANTY FORM

CUSTOMER DETAIL

Customer Name _____
 Address _____
 Telephone No _____ Cell Number _____ Postal Code _____
 E Mail Address _____

DISTRIBUTOR / FITMENT CENTRE DETAIL

Company Name _____
 Address _____ Contact Person _____
 Telephone No _____ Technician Name _____

VEHICLE DETAIL

Vehicle Make _____ Model _____ Year _____
 Registration No _____ VIN Number _____
 Odo/Speedo Reading _____

ACCESSORIES FRONT

Bumper	Yes	No
Winch	Yes	No
PDC's	Yes	No
Radar box	Yes	No
Bolt on towbar	Yes	No
Other	_____	

Surface coating _____

ACCESSORIES REAR

Bumper	Yes	No	
Spare wheel carrier	None	Single	Dual
PDC's	Yes	No	
Towball	Yes	No	
Wiring harness	Yes	No	
Other	_____		

Surface coating _____

ACCESSORIES

Bash plate	Yes	No
Lower c/arms	Yes	No
Transfer c/p	Yes	No
Rock Sliders	Yes	No
Roof rack	Yes	No
Other	_____	

INSTALLATION DETAIL

Torque checks	_____	NW	_____
Lock bolts	_____	NW	_____
Rubbers	_____		
Led lights	_____		

RE-CHECK DETAIL

Torque checks	_____
Lock bolts	_____
Rubbers	_____
Led lights	_____

Fitment Centre _____

Technician Name _____

COMPONENTS FITTED

Front	Winch plate	Yes	No
	Stiffeners	Yes	No
	Bumper Shell		
	Radiator plate	Yes	No
	Lights	Yes	No
	Resistors	Yes	No
	Other	_____	
	Serial #	_____	

Rear	Spine	Yes	No
	Shell	Yes	No
	Resistors	Yes	No
	Recovery points	Yes	No
	Bumper step	Yes	No
	Lights	Yes	No
	Towball	Yes	No
	Trailer plug	Yes	No
	Other	_____	
	Serial #	_____	

Signature : Fitment Centre (At Re-Check)

CUSTOMER DECLARATION

OTHER

Signature : Customer (At Re-Check)

Copy 1 - Customer copy after 500km Re-check
Copy 2 - Customers Copy at Installation
Copy 3 - To be returned to Wildog Acc
Copy 4 - Remain in book for Fitment Centre Records

Signature : Customer (At Fitment) _____ Signature : Fitment Centre (At Fitment) _____

It is essential to complete this card in full. Return to Wildog accessories via email to validate this warranty.
 No warranty form, no claim. Warranty will be void if retention is not done